	ENCLOSURE - 42"H	x 15-	3/4"	W ×	5"D, MAIN LUGS AT BOT	ТОМ	
CIR	STATUS		AKER	CIR	STATUS	BRE/ POLE	
1	SPARE	1	20	2	ACTIVE	1	20
3	ACTIVE	1	20	4	ACTIVE	1	20
5	SPARE	1	20	6	ACTIVE	1	20
7	SPARE	1	20	8	ACTIVE	1	20
9	ACTIVE	1	20	10	SPARE	1	20
11	ACTIVE	1	20	12	ACTIVE	1	20
13	ACTIVE	1	20	14	ACTIVE	1	20
15	ACTIVE	1	20	16	ACTIVE	1	20
17	SPACE AND BUS	1	-	18	SPACE AND BUS	1	-
19	SPACE AND BUS	1		20	SPACE AND BUS	1	
21	SPACE AND BUS	1	_	22	SPACE AND BUS	1	_
23	SPACE AND BUS	1	_	24	SPACE AND BUS	1	_

THERE ARE PRESENTLY 2 - #12 WIRES CONNECTED AHEAD OF THE CONTACTOR TO THE MAIN LUGS OF THE PANEL. THESE WIRES SHALL BE TRANSFERRED TO CIRCUITS 25 & 27 IN THE REPLACEMENT PANEL.

	ENCLOSURE - 42"	H v 15-			VIRE, 60 AMP MAINS		<u> </u>
		11 X 13-	3/4"	N ×	5"D, MAIN LUGS AT BOTT	ОМ	
CIR	STATUS	BRE POLE	AKER TRIP	CIR	STATUS	BREA POLE	TRI
1	SPARE	1	20	2	ACTIVE	1	20
3	ACTIVE	1	20	4	ACTIVE	1	20
5	SPARE	1	20	6	ACTIVE	11_	2
7	SPARE	1	20	8	ACTIVE	1	20
9	ACTIVE	1	20	10	SPARE	1	20
11	ACTIVE	1	20	12	ACTIVE	1	20
13	ACTIVE	1	20	14	ACTIVE	1	20
15	ACTIVE	1	20	16	ACTIVE	1	20
17	SPACE AND BUS	1		18	SPACE AND BUS	1	
19	SPACE AND BUS	1	-	20	SPACE AND BUS	1	
21	SPACE AND BUS	1	-	22	SPACE AND BUS	1	
23	SPACE AND BUS	1		24	SPACE AND BUS	1	-

	EX PANEL	SCH	ED	ULE	E - PANEL I	RL	
120	0/208 VOLTS, 3	PHAS	SE,	4 WIF	RE, 75 AMP MAIN	S, ML	.0
	ENCLOSURE -	42"H x	16"W	/ × 6"[	, MAIN LUGS AT TOP		
CIR	STATUS		AKER	CIR	STATUS	BRE.	AKER TRIF
	3 PC	OLE, 75 /	AMP L	IGHTING	CONTACTOR		
1 3	ACTIVE	OLE, 75 /	20	2	ACTIVE	1 1	
1 3	ACTIVE ACTIVE	OLE, 75 /			ACTIVE SPARE	1 1 1	20
1 3 5 7	ACTIVE ACTIVE ACTIVE	OLE, 75 /	20	2 4	ACTIVE	1 1 1 1	20
5	ACTIVE ACTIVE	OLE, 75 /	20 20 20	2 4 6	ACTIVE SPARE ACTIVE	1 1 1 1 1	20 20 20 -
5 7	ACTIVE ACTIVE ACTIVE ACTIVE	OLE, 75 /	20 20 20 20	2 4 6 8	ACTIVE SPARE ACTIVE SPACE AND BUS	1 1 1 1 1	20
5 7 9 11 13	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	OLE, 75 /	20 20 20 20 20	2 4 6 8	ACTIVE SPARE ACTIVE SPACE AND BUS	1 1 1 1 1 1 1	20 20 - -
5 7 9	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	OLE, 75 /	20 20 20 20 20 20 20 20	2 4 6 8 10	ACTIVE SPARE ACTIVE SPACE AND BUS SPACE AND BUS SPACE AND BUS	1 1 1 1 1 1 1	20 20 - -
5 7 9 11 13	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	OLE, 75 /	20 20 20 20 20 20 20 20 20 20	2 4 6 8 10 12 14 16 18	ACTIVE SPARE ACTIVE SPACE AND BUS	1 1 1 1 1 1 1 1	20 20 - - - -
5 7 9 11 13 15 17	ACTIVE	OLE, 75 /	20 20 20 20 20 20 20 20 20 20	2 4 6 8 10 12 14 16 18 20	ACTIVE  SPARE  ACTIVE  SPACE AND BUS  SPACE AND BUS	1 1 1 1 1 1 1 1 1	20 20 - - - - -
5 7 9 11 13 15	ACTIVE	OLE, 75 /	20 20 20 20 20 20 20 20 20 20	2 4 6 8 10 12 14 16 18	ACTIVE SPARE ACTIVE SPACE AND BUS	1 1 1 1 1 1 1 1 1	20 20 - - - - -

THE MAIN LUGS OF THE PANEL ARE TAPPED AHEAD OF THE CONTACTOR WITH 3 - #12. TWO OF THE #12 WIRES SUPPLY A 2 POLE, 20 AMP ENCLOSED CIRCUIT BREAKER AND 1 - #12 SUPPLIES A SINGLE POLE, 20 AMP ENCLOSED CIRCUIT BREAKER. BOTH CIRCUIT BREAKERS ARE LOCATED TO THE LEFT OF THE PANEL. ALSO, THE 2 POLE, 20 AMP CIRCUIT BREAKER IS TAPPED AND SUPPLIES AN EMERGENCY LIGHT TO THE RIGHT OF THE PANEL.

PK	OPOSED PAI	NEL	SC	H	EDULE - PANE		KL
12	0/208 VOLTS, 3	PHAS	SE,	4 V	WIRE, 75 AMP MAINS	, ML	0
	ENCLOSURE -	42"H x	16"W	/ x	6"D, MAIN LUGS AT TOP		
CIR	STATUS	BRE/ POLE	TRIP	CIR	STATUS	BRE/ POLE	
3	* ACTIVE	2	20	2	MAIN BREAKER	3	50
5	** ACTIVE SPACE AND BUS	1	20	8	SPACE AND BUS	1	
,	SI NOL NIID BOO				0,1102 1110 000		
	7 00	IE 60 A	MD I	ICLIT!	NC CONTACTOR		
	3 PO	LE, 60 A	AMP L	IGHTI	NG CONTACTOR		
9	3 POI	LE, 60 A	20	IGHTI	NG CONTACTOR  ACTIVE	1	2
11	ACTIVE ACTIVE	LE, 60 A	20	10	ACTIVE SPARE	1 1	2
11 13	ACTIVE ACTIVE ACTIVE	LE, 60 A	20 20 20	10 12 14	ACTIVE SPARE ACTIVE	1 1 1	2
11 13 15	ACTIVE ACTIVE ACTIVE ACTIVE	LE, 60 A	20 20 20 20	10 12 14 16	ACTIVE SPARE ACTIVE SPARE	1	2 2
11 13 15 17	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	LE, 60 A	20 20 20 20 20 20	10 12 14 16 18	ACTIVE SPARE ACTIVE SPARE SPARE SPARE	1	2 2 2 2
11 13 15 17 19	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	LE, 60 A	20 20 20 20 20 20	10 12 14 16 18 20	ACTIVE SPARE ACTIVE SPARE SPARE SPARE SPARE SPACE AND BUS	1 1 1	2
11 13 15 17 19 21	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	1 1 1 1 1 1	20 20 20 20 20 20 20 20	10 12 14 16 18 20 22	ACTIVE SPARE ACTIVE SPARE SPARE SPARE SPARE SPACE AND BUS SPACE AND BUS	1 1 1 1	2 2 2 -
11 13 15 17 19 21 23	ACTIVE	LE, 60 A	20 20 20 20 20 20 20 20	10 12 14 16 18 20 22 24	ACTIVE SPARE ACTIVE SPARE SPARE SPARE SPACE AND BUS SPACE AND BUS SPACE AND BUS	1 1 1 1 1 1	2 2 2 2
11 13 15 17 19 21	ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE ACTIVE	1 1 1 1 1 1	20 20 20 20 20 20 20 20	10 12 14 16 18 20 22	ACTIVE SPARE ACTIVE SPARE SPARE SPARE SPARE SPACE AND BUS SPACE AND BUS	1 1 1 1	2 2 2

- \* THE 2 #12 WIRE PRESENTLY CONNECTED TO THE MAIN LUGS OF THE PANEL AND SUPPLYING A 2 POLE, 20 AMP ENCLOSED CIRCUIT BREAKER SHALL BE CONNECTED TO THIS BREAKER.
- \*\* THE 1 #12 WIRE PRESENTLY CONNECTED TO THE MAIN LUGS OF THE PANEL AND SUPPLYING A SINGLE POLE, 20 AMP ENCLOSED CIRCUIT BREAKER SHALL BE CONNECTED TO THIS BREAKER.

3	TUNNEL UNDER CLASSROOM BUILDING	**	STAIRS FROM ENERGY PLANT
/—PANEL			
OL-T —PANEL			
EX-T			

TUNNEL - FLOOR PLAN - ELECTRICAL

SCALE: 1/8"=1'-0"



TUNNEL UNDER ADMIN. BUILDING

E	X & PROPOSE	D F	NI	, ,	SCH - PANEL	EX-	-T
1	20/208 VOLTS, 3 F	PHAS	E, 4	- W	IRE, 100 AMP MAINS	S, ML	_0
	ENCLOSURE - 24"	1 x 20	)"W ×	5-	1/2"D, MAIN LUGS AT TOP		
	271710	BRE	BREAKER		OTA THO	BREAKE	
CIR	STATUS	POLE	TRIP	CIR	STATUS	POLE	TRIP
1	ACTIVE	1	20	2	ACTIVE	1	20
3	ACTIVE	1	20	4	ACTIVE	1	20
5	ACTIVE	1	20	6	ACTIVE	1	20
7	ACTIVE	1	20	8	ACTIVE	1	20
9	SPACE AND BUS	1	_	10	SPACE AND BUS	1	-
11	SPACE AND BUS	1	_	12	SPACE AND BUS	1	-

E-5

D-018020

REVISIONS NO DATE DESCRIPTION SHEET TITLE

TUNNEL -FLOOR PLAN

AND PANEL **SCHEDULES** DESIGNED CHECKED APPROVED

FILE NO. 99037 DATE: OCT 25, 99

FINAL SUBMISSION

DRAWING NO.

OF 7